

Newline LYRA PRO Cheat Sheet

Turning On the Display

1. Press the Power button on the bottom right side of the display.
2. The button will change color from red to blue once the display is powered on.




The Front Ports

There are six ports located on the bottom left-hand side of the front of the panel: one USB Touch port, one HDMI port, two USB 3.0 ports, a USB Type-C with 65 watts power delivery port, and a mic-in port.



Switching Sources

1. Tap the Source icon on the home screen.
2. Any device currently connected to the display will light up in white in the Source window on the home screen.



3. Tap the icon of the source you want to switch to.
4. Plugging your device into the front ports will automatically bring up the device on screen.

Connecting a Computer


Connecting a Computer with USB-C

1. You will need a USB Type-C cable to connect a computer.
2. Plug in one end of the USB-C cable into the front or side USB-C port.
3. Take the other end of the USB-C port and plug it into the USB-C port on your computer.
4. Once both cables have been plugged into the display and the computer, the matching port should turn white on the Source window.



Connecting a Computer with USB & HDMI

1. You will need an HDMI cable and a USB A to B cable to connect a computer.
2. On the front or side ports of the Q Series, plug in one end of the HDMI cable into one of the HDMI ports.
3. Take the other end of the HDMI port and plug it into the HDMI port on your computer.
4. Plug in the USB-B end of the USB cable into one of the front or side ports labeled "USB Touch."
5. Take the USB-A end of the USB cable and plug it into the USB port on your computer.
6. Once both cables have been plugged into the display and the computer, the matching port should turn white on the Source window.




Newline LYRA PRO Cheat Sheet

Using the Home Screen Shortcuts

Google Search Bar

Search the web and the contents of your panel directly from the homescreen!



Android Toolbar

One the bottom on the panel screen is the Android toolbar. Use this toolbar for the following quick access tools:



Back

Goes back one screen or to the previous app. Can also be used to exit an app.

Home

Takes you to the main Home Screen.

Task Switcher

Pulls up all apps currently running on the panel.

Quick Access Toolbar

The Quick Access Toolbar can be accessed by tapping the white circle on either the left or right side of the screen. To minimize the Quick Access Toolbar, tap the white circle again.



OPS/Sources Shortcut

Takes you to the on-board computer (OPS). Tap and hold to pull up additional icons that can take you to the Sources menu, letting you easily switch between available sources.

Home Shortcut

Takes you to the main Home Screen.

Annotation Shortcut

Brings up whiteboarding options on top of whatever is on the current screen. Tap a second time to save a screenshot.

Whiteboard Shortcut

Takes you to the whiteboarding screen, letting you draw and takes notes instantly.

Quick Access Menu Button

Tap to open the Quick Access Menu. Tap again to minimize the menu.

Quick Access Bar

Opens up a menu to quickly access Classroom tools, calendar, calculator, clock, and more.

Sound Settings

Opens up a menu where you can adjust the sound settings.

Running Apps Shortcut

Pulls up all apps currently running on the panel.

Back Shortcut

Goes back one screen or to the previous app. Can also be used to exit an app.